

2 x 200g cloth strips each  
100mm wide, inside and out  
stagger joints to avoid bumps  
Overlap strips 25mm min

hull sheathing overlap chine joint 25mm as shown

add 1in x 1in beaching strips  
after sheathing (optional)

6mm ply hull skin

sheath cockpit sole  
extend over chine min 25mm

WL

WL

extend hull sheathing to 50mm  
above WL as minimum  
For maximum boat life it is best  
to sheath the whole boat

make outer chine joint and sheath while hull is upside down  
Turn hull on its side (port then starboard) to make inner chine joints  
Turn hull upright to make cockpit sheathing

sheathing glass shown dotted

chine glassing solid lines

fill sand fair using epoxy filler as required  
This is easiest to do before turning over

## Strike 18

11 Chine Glassing

Copyright WOODS DESIGNS  
Jan 2008