



Note: Dimensions to aft face bhd
Framing on fwd side all bhd's except 5
but allow for bevel on bhd's 6, Transom



There are two methods of positioning the bulkheads.
If building on a flat concrete or wood floor then "glue" cross blocks (eg 3in x 2in) to floor using Liquid Nails (or similar) or runny car body filler.
If building on uneven ground then make a building frame of two 4in x 2in (approx) timbers on edge about 400mm apart and mount the cross braces to them, see sketch and photo sheet.

These blocks can easily be knocked off the floor once the hull has been turned over



set up bhd's one at a time
using temporary braces as reqd

Strike 18

6 Hull Setup

Copyright WOODS DESIGNS
Jan 2008