



Soft loop over beam through eyelet  
Position approximate, but fit as far  
outboard as possible

Large eyelet on top of beam  
or incorporate into beam bolt

4mm (3/16in) wire

lanyard

U bolt through doubled lower wing stringer  
on each side forward beam box.  
Forward side only aft beam box.

**NOTE: If using the cabin or if sailing in Category C (coastal) rather than Cat D (sheltered water) then "waterstays" are recommended to help stiffen the beams**

**Strike 18**

Water stay

Copyright WOODS DESIGNS  
Jan 2008